


**Technical guidebook**

**User guide**

**Assembling**

**Maintenance**



# **WARM AIR GENERATOR**

**MOD. F85**


**MOD. F120**

**MOD. F240**

**YEAR OF MANUFACTURING**

**SERIAL NUMBER**

**Text Version  
01-10**



**FABBRI TERMOMECCANICA S.r.l.**  
**Via Cangiotti, 10**  
**61100 PESARO (PU)**  
**Tel.0721/282537 Fax 0721/282970**  
**[www.fabbritermomeccanica.it](http://www.fabbritermomeccanica.it)**  
**e-mail: [info@fabbritermomeccanica.it](mailto:info@fabbritermomeccanica.it)**

## **LEGEND**



**This symbol indicates danger, and will be used every time the operator's safety is involved.**



**This symbol indicates caution and is used to draw attention on very important operations needed for the proper and long-lasting use of the.**



**This symbol represents an environmental note, and draws attention on rules to follow for the environment's preservation.**

Dear Customer,

Before using the machine, it is important to read this handbook.

In order to ensure the operator's safety, the machine's devices must be kept in constant efficiency.

This booklet shows how to use and maintain the machine, and it is the operator's duty and responsibility to follow the present instructions.



**WARNING! The following instructions are meant for your safety.**

**Keep this booklet with care, for other operator's easy use.**

**The installation must be performed according to the manufacturer's instructions by trained personnel.**

**This machine must only be used for the purpose it has been built. Any other use is to be considered dangerous.**

**The machine must be used only by specifically trained personnel.**


**For any repair operations, always refer to a manufacturer-authorized assistance centre, and ask for original spare parts.**

**Disregarding any of the above might compromise the machine's safety.**

**MODEL** \_\_\_\_\_

**SERIAL NUMBER** \_\_\_\_\_

**YEAR OF MANUFACTURING** \_\_\_\_\_



**FABBRI TERMOMECCANICA S.r.l.**

**Via Cangiotti, 10**

**61100 PESARO**

**Tel.0721/282537 Fax 0721/282970**

**[www.fabbritermomeccanica.it](http://www.fabbritermomeccanica.it)**

**e-mail: [info@fabbritermomeccanica.it](mailto:info@fabbritermomeccanica.it)**

# INDEX

|   |           |
|---|-----------|
| <b>1 TECHNICAL SPECIFICATIONS .....</b>                       | <b>5</b>  |
| 1.1 MACHINE DESCRIPTION .....                                 | 5         |
| 1.2 APPLIED REGULATIONS.....                                  | 5         |
| 1.3 WORK STATION .....  | 6         |
| 1.4 PROTECTIONS.....  | 6         |
| 1.5 MODELS .....  | 7         |
| 1.6 IDENTIFICATION .....                                      | 7         |
| 1.7 ENCUMBRANCE .....   | 8         |
| 1.8 LABELLING .....   | 8         |
| 1.9 TECHNICAL SPECIFICATIONS .....                            | 9         |
| <b>2 INSTALLATION.....</b>                                    | <b>10</b> |
| 2.1 TRANSPORT .....   | 11        |
| 2.2 LIFTING AND HANDLING.....                                 | 11        |
| 2.3 ACCESSORIES .....   | 11        |
| 2.4 ENVIRONMENTAL SPECIFICATIONS .....                        | 12        |
| 2.5 INSTALLATION .....  | 13        |
| 2.6 MAINTENANCE SPACE .....                                   | 13        |
| 2.7 ELECTRIC PLUG-IN.....                                     | 14        |
| <b>3 OPERATION.....</b>                                       | <b>16</b> |
| 3.1 PRELIMINARY CONTROLS (version F85 CV - F120 - F240) ..... | 16        |
| 3.2 STARTUP .....   | 16        |
| 3.2.1 STARTUP (summer) .....                                  | 16        |
| 3.3 TWIN THERMOSTAT FUNCTIONING .....                         | 17        |
| 3.3.1 FAN FUNCTIONING.....                                    | 17        |
| 3.3.2 LIMIT FUNCTIONING .....                                 | 17        |
| 3.3.3 PLUGGING AND CALIBRATION .....                          | 17        |
| 3.1 PRELIMINARY CONTROLS (version F85 SV).....                | 18        |
| 3.1.2 CONTROLS DESCRIPTION.....                               | 18        |
| 3.2 STARTUP .....   | 18        |
| 3.2.1 STARTUP (summer) .....                                  | 19        |
| 3.4 OPERATION.....  | 20        |
| 3.5 REGULAR STOP .....  | 20        |
| <b>4 ORDINARY MAINTENANCE .....</b>                           | <b>21</b> |
| 4.1 PRELIMINARY CONTROLS .....                                | 21        |
| 4.2 CLEANING THE WARM AIR GENERATOR .....                     | 21        |
| 4.2.1 WIPING OFF THE ASH.....                                 | 22        |
| 4.2.2 CLEANING THE FLUE.....                                  | 22        |
| 4.2.3 CLEANING THE HEAT EXCHANGER .....                       | 22        |
| 4.3 FANBELT STRETCHING.....                                   | 22        |
| 4.4 REPLACING THE THERMOSTAT PROBE (version F85 SV) .....     | 23        |
| 4.5 REPLACING THE FUSE (version F85 SV) .....                 | 23        |
| <b>5 END OF SERVICE .....</b>                                 | <b>24</b> |
| <b>6 ACOUSTIC POLLUTION .....</b>                             | <b>24</b> |
| <b>7 SPARE PARTS CATALOGUE .....</b>                          | <b>25</b> |
| TAV. 1 SPARE PARTS F85 .....                                  | 26        |
| TAV. 2 SPARE PARTS F120-240 .....                             | 27        |
| TAV. 3 ELECTRIC PLAN F85-1SV .....                            | 28        |
| TAV. 4 ELECTRIC PLAN F85-2SV .....                            | 29        |
| TAV. 5 ELECTRIC PLAN F85-1CV .....                            | 30        |
| TAV. 6 ELECTRIC PLAN F85-2CV .....                            | 31        |
| TAV. 7 ELECTRIC PLAN F120-1 .....                             | 32        |
| TAV. 8 ELECTRIC PLAN F120-2 .....                             | 33        |
| TAV. 9 ELECTRIC PLAN F240-1 .....                             | 34        |
| TAV. 10 ELECTRIC PLAN F240-2 .....                            | 35        |

# **1 TECNICAL SPECIFICATIONS**

---

## **1.1 MACHINE DESCRIPTION**

This machine is a warm air generator which operates with solid fuel.

The framework is made up of a square profiled steel chassis and panels in galvanized polished steel.

On the chassis' lower part are located the vents for the air to be heated, which push the air inside the heat exchanger. The air is then expelled by exhaustion vents on the upper part of the machine.

The combustion chamber is chrome INOX steel, reinforced with ribs, and it is placed above the vents.

Inside, the furnace is separated from the cinerary by a steel grid.

The loading doors on the back of the machine are steel and internally coated in refractory materials. On the lower door you will find the shutter for regulating the combustion chamber's power.

The upper door, with a handle, is used to load fuel in the machine.

The fumes' exhaust pipe in the combustion chamber is linked to the heat exchanger above it.

The heat exchanger is made up of a series of pipes that run down the back and are linked to the draft mechanism, which is in turn operated by an external engine (except in the F85SV model).

On the control panel you will find the switches to start up the draft engine and the air heating vents.

## **1.2 APPLIED REGULATIONS**

### **Summary of laws and harmonized and technical rules**

1. Directive 2006/42/CE (Directive regarding Machines).

EN 292/1 Machine safety – fundamentals, general design principles – terminology, basic methodology.

EN 292/2 Machine safety – fundamentals, general design principles – technical specifications and principles.

EN 294 Machine safety – safety distance to avoid upper arms to make contact with dangerous parts - 1992.

EN 563 Machine safety – contact surface temperature. Ergonomic data to establish temperature values limits for heated surfaces. (june 1994).

UNI 8364 Heating systems – checkup and maintenance.

2. Directive 06/95/CE (Directive regarding low tension).

EN 60204-1 Machine safety – electric equipment Part 1 general requirements. - 1992 (revision of EN 60204-1).

EN 60529 Casing protection degrees (june 1991)

EN 60445 identification of terminals and drawn conductors, and rules for the alphanumeric

3. Directive 04/108/CE (Directive regarding EMC - electromagnetic compatibility).

EN 50081-2 electromagnetic compatibility – generic emission rule. Part 2: industrial environment

EN 50082-2 electromagnetic compatibility – generic immunity rule. Part 2: industrial environment.

### 1.3 WORK STATION

The machine need not be manned, therefore there is no need for an operator to use it, just to periodically reload fuel.

The operator's presence is required only when combustion is started.

### 1.4 PROTECTIONS


The machine is equipped with the following safety systems (Fig.1):

- Protection of the power grid with doorlock (pos.A).
- Mechanical protection in the loading area, coated in refractory materials (pos.B).
- Permanent mechanical protection using a galvanized steel sheet on the machine's sides (pos.C).
- Mechanical protection using a metal grid in the vents' suction tract (pos.D).
- Mechanical protection using a steel sheet reinforced with refractory materials in the heat exchanger's inspection tract (pos.E).
- Alarm (pos.F) (models F240-120 and F85SV only).

Furthermore, for the operator's safety we recommend:


- Protective suits
- Shockproof shoes
- Protective gloves

FIG.1



## 1.5 MODELS


**FIG.2**



## 1.6 IDENTIFICATION


When contacting the manufacturer, always provide the machine's serial number and year of manufacturing, found on the plate affixed on the right hand side (see fig.3).

FIG.3



## 1.6 IDENTIFICATION



**FIG.4**



| MODELS      | F28  | F55 S.V. | F55 C.V. | F85 S.V. | F85 C.V. | F120 | F240 | F350 |
|-------------|------|----------|----------|----------|----------|------|------|------|
| A (mm)      | 560  | 690      | 690      | 800      | 820      | 930  | 1100 | 1220 |
| B (mm)      | 1560 | 1750     | 1750     | 1980     | 1980     | 2200 | 2500 | 3000 |
| B1 (mm)     | 1900 | 2100     | 2100     | 2400     | 2400     | 2600 | 3000 | 3400 |
| C (mm)      | 920  | 1150     | 1150     | 1280     | 1280     | 1700 | 1900 | 2700 |
| C1 (mm)     | 920  | 1150     | 1520     | 1280     | 1690     | 2060 | 2290 | 3160 |
| WEIGHT (kg) | 170  | 260      | 305      | 365      | 415      | 615  | 850  | 1575 |

## 1.8 LABELLING

The machine features warning labels in the indicated areas (fig.5).



**FIG.5**

## 1.9 TECHNICAL SPECIFICATIONS

| <b>MODELS</b>  |                  | <b>F28</b>                     | <b>F55</b>       | <b>F85</b>      | <b>F120</b>     | <b>F240</b>     | <b>F350</b>     |
|--|------------------|--------------------------------|------------------|-----------------|-----------------|-----------------|-----------------|
| <b>DATA</b>  |                  |                                |                  |                 |                 |                 |                 |
| <b>Fuel</b>  |                  | <b>WOOD - CHIPPINGS - TURF</b> |                  |                 |                 |                 |                 |
| <b>Furnace power</b>   | (Kcal/h)<br>(KW) | 29900<br>34                    | 69000<br>80      | 99500<br>115    | 150000<br>175   | 300000<br>350   | 437000<br>510   |
| <b>Effective conventional power</b>                          | (Kcal/h)<br>(KW) | 25000<br>29                    | 55000<br>64      | 80000<br>93     | 120000<br>140   | 240000<br>279   | 350000<br>407   |
| <b>Air intake (m<sup>3</sup> /h)</b>                         |                  | 2200                           | 3500             | 6300            | 8900            | 17800           | 26000           |
| <b>Fuel consumption (Kg/h)</b>                               |                  | 13                             | 20               | 30              | 43              | 85              | 125             |
| <b>Vents electric power (HP)</b>                             |                  | 0,2                            | 0,35             | 1,5             | 3               | 4               | 6               |
| <b>Suction vents electric power (HP)</b>                     |                  | -                              | 0,35             | 0,35            | 0,75            | 0,75            | 1,5             |
| <b>Engine voltage (V)</b>                                    |                  | 220<br>(monoph.)               | 220<br>(monoph.) | 380<br>(triph.) | 380<br>(triph.) | 380<br>(triph.) | 380<br>(triph.) |
| <b>Chimney diameter (mm)<br/>(models without fumes vent)</b> |                  | 160 Ø                          | 180 Ø            | 180 Ø           | -----           | -----           | -----           |
| <b>Chimney diameter (mm)<br/>(models with fumes vent)</b>    |                  | -----                          | 180 Ø            | 180 Ø           | 200 Ø           | 200 Ø           | 250 Ø           |
| <b>Exhaust pipes diameter (mm)</b>                           |                  | 2x180Ø                         | 2x200Ø           | 2x250Ø          | 3x250Ø          | 3x300Ø          | 4x350Ø          |

## **2 INSTALLATION**

---



### **WARNING!**

**The generator's installation must be performed in observation of the current laws and technical rules, and its design must be performed by a freelance professional with regular profession registration**

### **HEATING SYSTEM DESIGN AND INSTALLATION**

#### **Law n. 46, 5th May 1990.**

“Rules for systems safety”.

#### **Law n.10, 9th January 1991.**

“Rules for enforcing the national energetic plan regarding energy rationing, energy saving, and development of renewable energy sources”.

#### **Presidential Decree n. 447, 6th December 199.**

“Rules for applying the Law n. 46, 5th May 1990, regarding systems safety.”

#### **Presidential Decree n.412, 26th August 1993**

“Rules for designing, installing, operating and maintaining heating systems in buildings towards the lowering of consumptions in respect of art. 4, paragraph 4 of the Law n.10, 9th January 1991.”

### **RULES FOR PREVENTING POLLUTION DURING HEATING SYSTEM INSTALLATION.**

#### **Law n. 615, 13th July 1966.**

“Rules against pollution”.

#### **Presidential Decree n. 1391, 22nd December 1970.**

“Rules for applying Law n. 615, 13th July 1966 with rules to prevent pollution, regarding heating systems”.

### **RULES FOR PREVENTING FIRES DURING HEATING SYSTEM INSTALLATION.**

#### **Minister of Internal Affairs Draft n.73, 29th July 1971.**

“Heating systems operating with oil fuel or oil gas – Rules against pollution. Rules to prevent fires.”

#### **Presidential Decree n.689, 26th May 1959.**

“Indication of companies and operations subject to controls by the Firefighters Command in order to prevent fires.”

#### **Ministerial Decree 16th February 1982.**

“Changes to Ministerial Decree 27th September 1965, dealing with companies subject to controls to prevent fires.”

#### **Decree n.246, 16th May 1987.**

“Rules for fire prevention in civilian buildings.”

## INSTALLATION RULES FOR THE ELECTRIC SYSTEM'S SAFETY.

### Law n. 186, 1st March 1968.

“Rules for producing and installing electrical and electronic systems, materials, and machines.”

### Italian Electro-technical Committee Rule 64-8.

Electric systems operating at a nominal tension non above 1000 V A/C and 1500 V D/C

## 2.1 TRANSPORT

The machine can be transported via truck, ship, train, and plane.

The machine is usually shipped wrapped in nylon, and the suction engine is dismantled.

All accessories are shipped separately.

## 2.2 LIFTING AND HANDLING

The machine can be lifted with a crane or freight elevator, using two hooked, clasped tows at least 1 meter long, or with a fork lift.

If lifted with a crane or freight elevator:

Place the hook end of the tows on top, and in the eyebolt in the lower part (fig. 6), placed in the plates welded on the exchanger.




### WARNING!

Lifting the machine with shorter tows can damage its upper parts.

## 2.3 ACCESSORIES

The only accessory for the machine is the fumes purifier, available on demand.



## 2.4 ENVIRONMENTAL SPECIFICATIONS

While positioning the machine, keep in mind that its functioning is guaranteed under an ambient temperature between 5°C and 40°C, and relative humidity between 35% and 75%

## 2.5 INSTALLATION



### - Package

**Do not throw the package in the trash, instead separate the various components according to materials (cardboard, wood, steel, polyester, and so on) and dispose of them according to your Country's laws**

The machine needs a solid support on the floor.

Position the machine according to its designated space.

Install the warm air diffusion vents (pos. 2 fig.7a-7b-7c).



### IF THE MACHINE HAS THE FUMES VENT:

**Install the fumes aspiration system (pos.4 fig.7a-7b-7c).**

Install the various tracts of the warm air generator's flue (pos.4, 5, 6 fig.7a-7b-7c).




### WARNING!

**You must install at least one special pipe T-shaped element in the flue (pos.7 fig.7a-7b-7c), which helps in cleaning operations.**


**MODELS F85 WITH FUMES VENT**

**FIG.7a**



## MODELS F85 WITHOUT FUMES VENT

FIG.7b



### WARNING!

The initial vertical section of the flue should never measure more than 2 or 3 meters in length (pos. 5 fig.7a-7b-7c) before applying the T-shaped tract (pos.7 fig.7a-7b-7c).

## MODELS F120 F240








FIG.7c

**FIG.8**

|             | <b>A</b> | <b>B</b> | <b>C</b> | <b>D</b> |
|-------------|----------|----------|----------|----------|
| <b>F28</b>  | 1000     | 600      | 600      | 1500     |
| <b>F55</b>  | 1000     | 600      | 600      | 1500     |
| <b>F85</b>  | 1000     | 600      | 600      | 1500     |
| <b>F120</b> | 1200     | 600      | 600      | 1800     |
| <b>F240</b> | 1200     | 600      | 600      | 1800     |
| <b>F350</b> | 1200     | 600      | 600      | 2000     |

The values in the table are expressed in mm.

## 2.6 MAINTENANCE SPACE

During installation of the machine, it is advisable to set up an area for later maintenance operations, as indicated in fig. 8.



**IMPORTANT:** the values in the tables are the recommended minimum values.

## 2.7 ELECTRIC PLUG-IN



### WARNING!

Before plugging in, make sure you have a proper grounding system which follows the current European Laws (EN).

Check the compatibility of the network voltage with the specifications in the appropriate label in the machine (fig. 2).

Power fluctuations greater than  $\pm 10\%$  of the nominal voltage indicated in the label can cause serious damage on the machine. That damage is not covered by the warranty.



**IMPORTANT:** verify that the power cable is the right size.

Turn the switch on the 0 position in the F85 CV-F120-F240 models (pos. A fig.11), in the F85 (pos. A fig.11B).

Insert the machine's power cable through the gland under the power grid (pos. B fig.7). Connect wires in the terminal by following the attached electric plan (TAV. 2) and following.



### IF THE MACHINE HAS THE FUMES VENT:

Plug the fumes suction grid's cable (pos. C fig.7).

Once the cable has been plugged, the suction vents' orientation should be checked.

In the F85 CV-F120-F240 models, proceed as follows:


- Turn on the manual operation of the vents' thermostat (press the white button) (fig.9);
- Turn on the general switch (fig.10);

- Make sure the vents' orientation in correct (refer to the arrows on the fans)




**WARNING!**

Should this checkup be skipped, the combustion chamber could be damaged during the first startup, due to overheating of the entire machine.




**FIG.9**



**FIG.10**

In the F85 SV model, proceed as follows:

- Turn on the general;
- Press the “FAN” button to start up the vents (fig.10b);
- Make sure the vents' orientation in correct (refer to the arrows on the fans)



**FIG.10b**

# 3 OPERATION


In the F85CV - F120- F240 models

## 3.1 PRELIMINARY CONTROLS



**WARNING!** Before starting up the machine make sure that:

- The power grid's general switch is turned off (pos. OFF).
- The machine's general switch is turned on 0 (pos.A fig. 11).
- All installation and assembling has been performed correctly, especially during orientation of the vents.



## 3.2 STARTUP (summer)

Turn on the machine's general switch (fig.11 pos.B). Turn on the fumes vent by pressing its button (fig.12 pos.1).

Load the fuel using the grid in the machine's upper part.

Turn on fuel loading and wait for combustion to start up.



**WARNING!**  
Do not use liquid fuel.



**WARNING!**  
If the machine has got a fumes vent, do not turn it off during combustion.

To adjust combustion, regulate suction power in the lower (fig.13 pos.3).

The thermostat that regulates the vents' startup is already set at a temperature between 30°C and 40°C.




The alarm's thermostat is already set to activate at 90°C.

When the desired temperature has been reached, the air vents will activate automatically (press the white button, turn it on automatic position) (fig.14).

### 3.2.1 STARTUP (summer)



**IMPORTANT:** to turn on cold air circulation, press the fumes vent button (pos.3 fig.16) in absence of combustion.



### 3.3 TWIN THERMOSTAT OPERATION

The thermostat's sensor is placed on the suction vent. It can start and stop the ventilation system (FAN function), and regulates the overheating alarm mechanism (LIMIT function) when it is available.

#### 3.3.1 FAN FUNCTION

When the ambient temperature near the sensor reaches the value set on the twin thermostat's board ( $40^{\circ}\text{C}$ ), an electric contact in the thermostat will be closed, and the ventilation system will activate.

When the ambient temperature near the sensor drops lower than the value set on the twin thermostat's board ( $30^{\circ}\text{C}$ ) an electric contact in the thermostat will be opened, and the ventilation system will stop.

#### 3.3.2 LIMIT FUNCTION

When the air in proximity of the sensor is overheated due to an anomaly, and the temperature reaches the value set on the twin thermostat's board ( $100^{\circ}\text{C}$ ), an electric contact in the thermostat will be closed, and the alarm will activate.

#### 3.3.3 PLUGGING AND CALIBRATION


The warm air generator's wirings are already plugged, and the twin thermostat is already calibrated. Should you need to perform those operations again (in case of maintenance, checkups, or replacements), please follow the instructions below (fig. 15):

##### Legend:

1. Wirings for FAN function.
2. Twin Thermostat's board.
3. Fastening holes.
4. Ventilation system's stop temperature indicator.
5. Ventilation system's start temperature indicator.
6. LIMIT function's activation temperature indicator.
7. Holes for wires block. By inserting the tip of a screwdriver in this hole, the clamp will be blocked, and it will be possible to insert a wire. Removing the tip of the screwdriver will automatically block the wire inside the clamp.



**WARNING!** Make sure the wire is tightly blocked inside the clamp by gently pulling it.



**FIG.15**

8. Wirings for LIMIT function.
9. Metal bridge10.

White button for automatic (raised) or manual (pressed) ventilation.



##### IMPORTANT!

**The metal bridge (9) must be removed in all models.**

**When adjusting values (4) (5) (6) do not turn the board (2), or the twin thermostat will be damaged.**

### **3.1 PRELIMINARY CONTROLS**




**WARNING!** Before starting up the machine make sure that:

The power grid's general switch is turned off (pos. OFF).

The machine's general switch is turned on 0 (pos.1 fig. 11).

All installation and assembling has been performed correctly, especially during orientation of the vents.



**FIG.16**

#### **3.1.2 CONTROLS IN THE ELECTRONIC PANEL**

- 1) General switch.
- 2) fumes vent button.
- 3) air vent button.
- 4) fumes vent light (green).
- 5) air vent light (green).
- 6) alarm light (red).
- 7) temperature display.

### **3.2 STARTUP**

Turn on the machine's general switch (pos.1B fig.11).

Load the fuel using the grid in the machine's upper part.

Turn on fuel loading and wait for combustion to start up.



**WARNING!**

**Do not use liquid fuel.**



**WARNING!**

**If the machine has got a fumes vent, do not turn it off during combustion.**

To adjust combustion, regulate suction power in the lower door (pos.3 in fig.13).

When temperature reaches 45°C, the air vents will activate automatically (pos.5 in fig.16), and they will automatically switch off as well when temperature drops below 41°C.

The alarm's thermostat is already set to activate at 90°C.

### 3.2 STARTUP (summer)



**IMPORTANT: to turn on cold air circulation, press the fumes vent button (pos.3 fig.16) in absence of combustion.**

### 3.4 OPERATION

The machine must only be loaded with fuel via the upper door (pos. 1 in fig.13). Fuel examples include:



- Dry wood not treated with chemicals.
- Wood chippings pressed in bundles.



**WARNING! Do not use powdered wood, nor liquid fuel, during startup and combustion.**

#### Removing ashes.

Remove ashes only after combustion has ceased, and only after temperature has dropped below 40°C, then:

- open up the two front doors (pos. 1 and 2 in fig.13).



**IMPORTANT: the lower door will not open if the upper door is open.  
The lower door is closed with a knobbed screw.**

- Empty the cinerary.
- Close the doors.



**IMPORTANT: do not place the ashes near the vents' suction area (fig. 17).**




**WARNING! Do not overload the machine. An excessive heat generated by combustion could deform the machine's structure.**

When the warm air generator is on, there is a chance that the alarm will be set off. This is due to the excessive heat generated by the furnace. In this case, lower the heat generation by shutting down the air suction (pos. 3 in fig. 13), and stop loading fuel.



**WARNING! Do not let the alarm activated for more than 2 minutes, or the wirings could be damaged.**



### 3.4 REGULAR STOP

You can turn off the furnace by shutting down the air suction (pos. 3 in fig. 13)

Then, after the machine has cooled down, switch off the flue's suction and the vents (pos. 0 in fig. 11), and finally turn off the machine's general switch.



**WARNING!  
Do not turn off the general switch before combustion has ceased and the ashes are cold.**

# 4 ORDINARY MAINTENANCE


## 4.1 PRELIMINARY CONTROLS



**WARNING!** Before maintenance, make sure that:

- The power grid's general switch is turned off (pos. OFF).
- The machine's general switch is on 0 (Fig. 18), that a padlock is placed on the appropriate lock, and its keys given to the safety operator.
- Make sure the machine is not powered during maintenance operations.

**FIG.18**




## 4.2 CLEANING THE WARM AIR GENERATOR



**IMPORTANT:** at season's end, clean the combustion chamber, the flue, and the heat exchanger's pipes.

**FIG.19**



#### **4.2.1 WIPPING OFF THE ASH**

Every time the machine is stopped, the ash on the bottom of the combustion chamber must be removed

#### **4.2.2 CLEANING THE FLUE**

To proceed with cleaning you must:

- Unplug suction (pos. A in fig. 19).
- Unplug the flue from the suction (pos. B in fig. 19).
- Remove soot from the flue with an iron brush.
- Reassemble flue with suction.
- Plug suction.

#### **4.2.3 CLEANING THE HEAT EXCHANGER**

To proceed with cleaning you must:


- remove back protection panel (1 in fig. 19) by unscrewing it.
- unplug suction (pos. A in fig.19).
- remove the rest of the back protection panels by unscrewing them (pos.2, 7 fig.19).
- clean the exchanger's pipes with a helix-shaped iron brush, from the front of the machine (pos. 4 in fig.19).
- do the same for the descending vertical pipes (pos.5 fig.19).
- install back the protection panels (part. 1,2 and 7 fig.19).
- plug suction (pos.A fig.19).
- plug flue with suction.

#### **4.3 FANBELT STRETCHING (models F120-F240 only)**

You should periodically stretch the fan belts.

To access the fan belts, remove the protection grids (part. 6 fig. 19).

- Regulate the fan belts' stretching with the registry screw (fig. 20).
- In case this doesn't work, replace the belt.
- At operations complete, replace the protection grid.




#### **4.4 REPLACING THE THERMOSTAT PROBE (model F85 SV only)**

To replace the thermostat probe:

- unscrew the probe holder (pos.A fig.21);
- remove the probe holder and remove the central screw (pos.B fig.21) in the probe's lodge;
- unplug the probe's lodge by unscrewing it (pos.C and pos.D fig.21);
- replace the probe and reverse the above operations.

**FIG.21**



#### **4.5 REPLACING THE FUSE (model F85 SV only)**

The fuse lies inside the electronic panel. To replace it, consult the electric plans (tav.2-tav.3).

## **5 END OF SERVICE**

---



**When the machine's lifetime is up, you should:**

- remove all rubber parts (O-ring, gaskets, girds, etc...).
- remove all recyclable plastic components (thermoplastic parts) and separate them from the unrecyclable ones (thermo-resistant parts).
- remove all copper parts (cables).

Dispose of the different materials according to your Country's laws.

## **6 ACOUSTIC POLLUTION**

---



The sound emission levels for the models F 85 F120 and F240 have been tested according to the ISO 11202 rules, and the following maximum sound thresholds have been recorded:

| <b>MODEL</b>                           | <b>L<sub>pA</sub> (dB(A))</b> |              |              |
|--|-------------------------------|--------------|--------------|
|  | <b>F85</b>                    | <b>F 120</b> | <b>F 240</b> |
| Machine with only fumes vent turned on | < 60                          | < 60         | < 60         |
| Machine with only warm air vent        | 66,6                          | 70,6         | 73,4         |
| Machine with both vents turned on      | 66,7                          | 70,9         | 74,1         |

**L<sub>pA</sub>:** Max sound pressure level recorded on the operator's work station

## **7 SPARE PARTS CATALOGUE**

---


### **HOW TO ORDER SPARE PARTS**

To order spare parts, the following specifications must be presented:


- Machine type (model, serial number, year of manufacturing).
- Spare part description.
- Quantity needed.
- Any indications the spare part might have engraved on a plate.


| N° | DESCRIZIONE  | N° | DESCRIPTION                                 | N° | BEZEICHNUNG                                     |
|----|--|----|---|----|---|
| 1  | SONDA TEMPERATURA ARIA                               | 1  | AIR TEMPERATURE SENSOR                      | 1  | TEMPERATURFÜHLER                                |
| 2  | TERMOSTATO ACCENSIONE<br>ARIA                        | 2  | A I R     A C T I V A T I O N<br>THERMOSTAT | 2  | EINSCHALTHERMOSTAT<br>LUFT                      |
| 3  | TERMOMETRO INDICATORE                                | 3  | THERMOMETER INDICATOR                       | 3  | ANZEIGETHERMOMETER                              |
| 4  | QUADRO ELETTRICO                                     | 4  | ELECTRIC CONTROL PANEL                      | 4  | SCHALTTAFEL                                     |
| 5  | GRIGLIA DI APPOGGIO SCAR-<br>TI                      | 5  | REJECTED MATERIAL SUPPORT                   | 5  | GITTER ABFALLABLAGE                             |
| 6  | SPORTELLO DI CONTROLLO<br>ESTRAZIONE CENERI          | 6  | ASH EXTRACTION CONTROL<br>PANEL             | 6  | KONTROLLTÜR<br>ASCHEENTNAHME                    |
| 7  | SPORTELLO CARICAMENTO<br>MANUALE                     | 7  | MANUAL LOADING PANEL                        | 7  | TÜR ZUM MANUELLEN<br>BELADEN                    |
| 8  | SPORTELLO PULIZIA TUBI                               | 8  | PIPE CLEANING PANEL                         | 8  | TÜR ZUR ROHRREINIGUNG                           |
| 9  | BOCCHE DI MANDATA ARIA<br>CALDA                      | 10 | HOT AIR OUTLET OPENINGS                     | 9  | ZULUFTSTUTZEN WARM<br>LUFT                      |
| 10 | GRATA DI ASPIRAZIONE                                 | 11 | SUCTION GRATING                             | 10 | SAUGGITTER                                      |
| 11 | GRUPPO DI ASPIRAZIONE<br>ARIA                        | 12 | AIR SUCTION ASSEMBLY                        | 11 | BÄUGRUPPE                                       |
| 12 | GRUPPO DI ASPIRAZIONE FUMI<br>E SPORTELLO PER CENERE | 13 | SMOKE SUCTION ASSEMBLY<br>AND ASH PANEL     | 12 | LUFTANSÄUGUNG<br>DAMPFABSAUGUNG UND<br>ASCHETÜR |
| 13 | SIRENE DI ALLARME                                    |    | ALARM SIREN                                 | 13 | ALARMSIRENE                                     |


F 85 WITH FUMES VENT




F 85 WITHOUT FUMES VENT









#### TLC 1 CONNECTIONS

| STANDARD  | SHEET   |
|-----------|---------|
| F85<br>SV | 2 - 2 - |

#### DEFINITIONS

- Ib - Actual applied current (device absorption)
- In - Nominal current
- Ir - Regulated current
- Pn - Nominal active power
- Vn - Nominal voltage (of the appliance)

#### LEGEND

- I - Distribution switches
- RT - Temperature relays
- T - Thermostat contact
- M - Motors
- C - Contactors

#### NOTE

- The thermostats marked (T), with contacts indicated by various numbers, either refer to one thermostat with several different intervention thresholds or to individual thermostats (one for each number).
- The control panel face plate dimensions indicated are intended as a guideline only.



- The protection class of the control panel and the corresponding connections to individual pieces of furnace equipment must be at least IP44.
- The main switch handles interlock with the cover.

- The control panel may only be opened when the switch is in the open position.


#### N.B.


- During installation, the Purchaser must protect the hot air generator from "Indirect Contact", in compliance with current CEI standards.
- We recommend the use of a diff. switch with a 30 mA cut-off threshold, which will protect the main power supply line.

#### CONTROL PANEL FACE PLATE




#### TERMINAL BOARD





|  |  |
|--|--|
| <p><b>TAV.6</b></p>                    | <h3>ELECTRIC PLAN F85-2 WITH FUMES VENT</h3> |
| <p><b>CONTROL PANEL FACE PLATE</b></p> |  |

#### TLC 1 CONNECTIONS



| STANDARD        | SHEET  |
|-----------------|--------|
| F85<br>with Fan | 2<br>- |

#### DEFINITIONS

- Ib - Actual applied current (device absorption)
- In - Nominal current
- Ir - Regulated current
- Pn - Nominal active power
- Vn - Nominal voltage (of the appliance)

#### LEGEND

- I - Distribution switches
- RT - Temperature relays
- T - Thermostat contact
- M - Motors
- C - Contactors

#### NOTE

The thermostats marked (T), with contacts indicated by various numbers, either refer to one thermostat with several different intervention thresholds or to individual thermostats (one for each number).

The control panel face plate dimensions indicated are intended as a guideline only.

The protection class of the control panel and the corresponding connection to individual pieces of furnace equipment must be at least IP44.


The main switch handles interlock with the cover. The control panel may only be opened when the switch is in the open position.

#### N.B.

During installation, the Purchaser must protect the hot air generator from "Indirect Contact", in compliance with current CEI standards.  
We recommend the use of a diff. switch with a 30 mA cut-off threshold, which will protect the main power supply line.

#### TERMINAL BOARD

|   |   | To Ventilation Fan |   | To Smoke Fan |   | NTC Temp. Sensor |   |
|---|---|--------------------|---|--------------|---|------------------|---|
|   |   | U                  | V | W            | U | V                | W |
| 1 | 2 | 3                  | 4 | 5            | 6 | 7                | 8 |




FAN TEMP SET  
ALARM TEMP SET  
FUN HYSTERESIS



## CONTROL PANEL FACE PLATE

## TLC 1 CONNECTIONS

STANDARD  
F120SHEET  
2

## DEFINIZIONI

Ib - Actual applied current  
(device absorption)In - Nominal current  
Ir - Regulated current

Pn - Nominal active power

Vn - Nominal voltage of the appliance

## LEGEND

I - Distribution switches

RT - Temperature relays

T - Thermostat contact

M - Motors

C - Contactors

## NOTE

The thermostats marked (T), with contacts indicated by various numbers, either refer to one thermostat with several different intervention thresholds or to individual thermostats (one for each number).

The control panel face plate dimensions indicated are intended as a guideline only.


The protection class of the control panel and the corresponding connections to individual pieces of furnace equipment must be at least IP44.

The main switch handles interlock with the cover. The control panel may only be opened when the switch is in the open position.

## N.B.

During installation, the Purchaser must protect the hot air generator from "Indirect Contact" in compliance with current CEI standards.  
We recommend the use of a diff switch with a 30 mA cut-off threshold, which will protect the main power supply line.

FAN TEMP SET  
FAN HYSSTERESIS  
ALARM TEMP SET



FABBR.  
TERMOMECCANICA


| STANDARD | SHEET   |
|----------|---------|
| F240     | 1 - 2 - |

### DEFINITIONS

- Ib - Actual applied current (device absorption)
- In - Nominal current
- Ir - Regulated current
- Pn - Nominal active power
- Vn - Nominal voltage (of the appliance)

### LEGEND

- I - Distribution switches
- RT - Temperature relays
- T - Thermostat contact
- M - Motors
- C - Contactors



| CIRCUIT           | CIRCUIT DESCRIPTION  | MAIN SWITCH  | VENTILATION FAN MOTOR | SMOKE FAN MOTOR         |            | TLC 1 |
|-------------------|----------------------|--------------|-----------------------|-------------------------|------------|-------|
|                   |                      |              |                       | OVERLOAD CUT-OUT        | PROTECTION |       |
| ACTIVE POWER      | kW                   | 3.65         | 3                     |                         | 0.56       |       |
| APPLIED CURRENT   | Ib                   | A            | 9.2                   | 7.2                     | 1.6        |       |
| PHASES            | N                    |              | 4                     | 3                       | 3          |       |
| NOMINAL CURRENT   | In                   | A            |                       | 6.3/10                  | 1.6/5      |       |
| REGULATED CURRENT | Ir                   | A            |                       | 7.6                     | 1.7        |       |
| CUT-OFF POWER     |                      |              |                       | 50 (BACK-UP WITH FUSES) | 100        |       |
| CONTACTOR         | Pn (AC3)<br>Vn<br>In | kW<br>V<br>A |                       | 4                       | 400        |       |
| SWITCH            | Pn<br>Vn<br>In       | kW<br>V<br>A |                       | 400                     | 16         |       |
| BASE              |                      | A            |                       | 16                      |            |       |
| FUSE              |                      | A            |                       | 10                      |            |       |
| VALVES            |                      |              |                       |                         |            |       |

## CONTROL PANEL FACE PLATE

## TLC 1 CONNECTIONS

